



Clemas & Co Ltd

Industrial Cleaning Equipment
Sales - Hire - Service

GEL BATTERY CARE & MAINTENANCE

DO

- ⇒ Ensure the top of the battery is clean and dry
- ⇒ Switch off charger before disconnecting battery
- ⇒ Ensure all connections and bolted terminals are tight and covered with petroleum jelly. Use insulated tools when removing or replacing terminals.
- ⇒ Wear protective clothing.

DO NOT

- ⇒ Overcharge or undercharge the battery. Use only the correct type and size of charger approved by Clemas & Co Ltd.
- ⇒ Put any metal objects on top of the battery
- ⇒ Leave discharged battery in that state for over 24 hours
- ⇒ Smoke or allow naked flames near the battery, especially when charging
- ⇒ Re-charge the battery for longer periods than necessary to restore capacity used
- ⇒ Repair or re-set the charger. Any setting or necessary repair should be undertaken by qualified personnel, using approved components. Contact our Service Department for further information.

Please note: This is general guidance only, for specific instructions on battery maintenance for your particular machine, please refer to your user manual or contact the service department on 01684 850777

Clemas & Co Ltd.

Unit 16 Ashchurch Business Centre, Alexandra Way, Tewkesbury, Gloucestershire, GL20

T: 01684 850777 8NB 01684 850707

E: info@clemas.co.uk

W: www.clemas.co.uk